


# EME VD **v1.02**

***Voltage regulator for generators***



**January 2006**

**Instruction Manual**



## WARNINGS



### WARNING

The system should not be installed, operated, serviced or modified except by qualified personnel who understand the danger of electric shock hazards and have read and understood the user instructions



### WARNING

Never work on a LIVE generator. Unless there is another person present who can switch off the power supply or stop the engine

### WARNING

Dangerous voltages are present at the voltage regulator board. Accidental contact with live conductors could result in serious electrical shock or electrocution. Disconnect the power source before making repairs, connecting test instruments, or removing or making connections to the voltage regulator or generator.



**ELECTRICAL HAZARDOUS VOLTAGES  
DANGEROUS DO NOT OPERATE WHEN  
NOT FAMILIAR WITH GENERATORS**



The manual does not cover all technical details of the product. Specifications may be modified by the manufacturer without notice. For further information, the manufacturer should be contacted.

---

## Table of contents

|   |           |
|---|-----------|
| <b>WARNINGS</b>                               | <b>2</b>  |
| <b>Chapter 1 Introduction</b>                 |           |
| <b>1.0 General description</b>                | <b>4</b>  |
| <b>1.1 AVR Layout</b>                         | <b>5</b>  |
| <b>1.2 Absolute maximum ratings</b>           | <b>6</b>  |
| <b>1.3 Commissioning information</b>          | <b>7</b>  |
| <b>Chapter 2 Installation and maintenance</b> |           |
| <b>2.0 Connection diagram</b>                 | <b>8</b>  |
| <b>2.1 Running state and LED error codes</b>  | <b>9</b>  |
| <b>2.2 Power-up routine and diagnose</b>      | <b>10</b> |
| <b>2.3 Adjusting and factory settings</b>     | <b>11</b> |
| <b>2.4 Special functionality</b>              | <b>12</b> |
| <b>2.5 Electrical characteristics</b>         | <b>12</b> |
| <b>2.6 Wiring diagram</b>                     | <b>13</b> |
| <b>2.7 Fault diagnostics (diagrams)</b>       | <b>14</b> |
| <b>2.8 Factory settings</b>                   | <b>17</b> |
| <b>2.9 General installation information</b>   | <b>18</b> |

---

# 1. INTRODUCTION

## 1.0 General description

This manual contains instructions for installing, operating and maintaining the EME VD automatic voltage regulator (AVR).

The AVR is specifically designed for railway application according EN 50155 in combination with brushless generators 400 V/50 Hz.

It is however very applicable for generator installations where high demands for the accuracy and safety for the generator output are requested.

The AVR is equipped with security functions to protect the generator load and equipment from damage or dangerous situations. Critical protections are implemented redundant. The protection circuits as well as the operational status feedback interface contact are tested upon every power up, before the generator is excited by the AVR.

The AVR is designed to meet the railway requirements described in the EN 50155:2004, rolling stock.

This contains the environmental aspects as well as the electrical aspects such as EMC emission and immunity, supply voltage range, and overvoltage protections.

Under normal conditions the AVR is placed inside the generator but installation in cabinets is also possible.

The AVR is partly software controlled and deliverable with special functions such as soft voltage recovery at voltage dips upon switched on heavy loads, when using soft prime movers such as a hydraulic motor.

The AVR is available for 0-110V<sub>dc</sub> as well as 0-24V<sub>dc</sub> supply voltage.

## 1.1 AVR Layout

The AVR is protected from the environment by an epoxy coating.

The bottom of the AVR has a special Protective Earth (PE) connection surface shown as PE in figure 2.

Connection terminals are locked by screws and are not exchangeable as a consequence of a coding system.




Fig 1. Top view AVR (Measurements in mm)

## (AVR layout continued)




Fig 2. Rear view of the AVR (Measurements in mm)

## 1.2 Absolute maximum ratings

| Symbol             | Parameter                     | Condition  | Min.    | Max.   | Unit            |
|--------------------|-------------------------------|--|---------|--------|-----------------|
| U,V,W              | Voltage sensing input         | < 30 s. 50 Hz.   | -       | 500    | V <sub>ac</sub> |
| J1, K1             | Field excitation current      | Typical 4 A <sub>dc</sub>  |         | 5      | A <sub>dc</sub> |
| UH, VH<br>UH', VH' | Supply input                  | 1- or 3-phase.<br>or two 1-phase dc -<br>400 Hertz               | 20      | 240    | V               |
| R <sub>field</sub> | Field resistance              | @ 100 V <sub>UH-VH</sub> (rms)<br>@ 230 V <sub>UH-VH</sub> (rms) | 4<br>10 | -<br>- | Ohm<br>Ohm      |
| T <sub>amb</sub>   | Operating ambient temperature | 100 % RHD<br>non condensing                                      | -20     | +85    | °C              |
| T <sub>stg</sub>   | Storage temperature           | 95 % RHD<br>non condensing                                       | -45     | +85    | °C              |
| NO, C              | Operational output            | Isolated   |         | 5A/30V | DC              |
| T36, T37           | Clixon input                  | Isolated   | 0       |        | Ohm             |
| 1, 2               | Droop input                   | Isolated   |         | 0.5    | A <sub>ac</sub> |
| 0-24 V             | Electronics supply            | Isolated   | 18      | 39     | V <sub>dc</sub> |
| 0-110V             | Electronics supply            | Isolated   | 77      | 138    | V <sub>dc</sub> |
| s, t               | External Volt adjust          | - 5%   | 0       | 5K     | Ohm             |
|                    | Accuracy                      | THD < 5 %  |         | 1 %    |                 |

Table 1. Absolute maximum ratings

---

## 1.3 Commissioning information

The system should not be installed, operated, serviced or modified except by qualified personnel who understand the danger of electric shock hazards and have read and understood the user instructions.

Defects in the generator or AVR may cause consequential loss. Precautions must be taken to prevent this from occurring.

Never work on a LIVE generator. Unless there is another person present who can switch off the power supply or stop the prime mover.

Dangerous voltages are present at the voltage regulator board. Accidental contact with live conductors could result in serious electrical shock or electrocution. Disconnect the power source before making repairs, connecting test instruments, or removing or making connections to the voltage regulator.

The unit should be installed with respect to the environmental specifications as well as the rules mentioned in the General installation information.


For safety reasons the voltage LEVEL potentiometer is best turned completely counter clockwise in order to start at the lowest possible voltage.

## 2. INSTALLATION AND MAINTENANCE

For safety reasons the voltage LEVEL potentiometers are best turned completely counter clockwise in order to start at the lowest possible voltage

### 2.0 Connection diagram

For a complete wiring diagram see figure 4 on page 12.



| Symbol    | Description                                   | Notes                             |
|-----------|---|-----------------------------------|
| U, V, W   | Voltage sensing input                         |                                   |
| 1 & 2     | Droop input                                   | 0,5 A <sub>ac</sub> max (Vphase)  |
| S & T     | External connector for remote voltage control | When used, remove bridge          |
| 0 – 110 V | External electronic supply                    | 24 V <sub>dc</sub> also available |
| K1 & J1   | AVR field excitation                          |                                   |
| UH & VH   | Supply input                                  |                                   |
| UH' & VH' | Supply input                                  |                                   |
| C & NO    | Status contact                                | Closed when AVR operational       |
| T36 & T37 | Clixon input                                  | Overtemperature when open         |

Table 2. Connecting diagram



## 2.1 Running state and LED error codes

**Important: By removing the 110V<sub>dc</sub> (or 24V<sub>dc</sub>) power supply, error codes will be lost!**

To read out the error code, the 110V<sub>dc</sub> (or 24V<sub>dc</sub>) power supply must remain connected after an error occurred. In order to reset the AVR, remove the 110V<sub>dc</sub> (or 24V<sub>dc</sub>) power supply for at least 5 seconds.



Green LED off: Diagnose fault AVR, AVR not running













Green LED on: No diagnose fault, AVR running




Red LED on: Fault and error, AVR not running



Table 2. LED status and corresponding error codes

| No. of Blinks Red LED   |   | Error Description                    |                  |         |        |
|---|---|--------------------------------------|------------------|---------|--------|
|   |   | Green LED off                        | Green LED On     |         |        |
|   |   |                                      | Value            | Time    |        |
| 1   |   | Operational contact selftest failure | Undervoltage     | 380V    | > 5 s  |
| 2   |  | Supply relais selftest failure       | Undervoltage     | 340V    | > 1 s  |
| 3   |  | Overvoltage selftest failure         | Overvoltage      | 420V    | > 5 s  |
| 4   |  | Error reset selftest failure         | Overvoltage      | 440V    | > 1 s  |
| 5   |  | Overtemperature selftest failure     | Overvoltage      | 500V    | >0,1s  |
| 6   |  | Measurement selftest failure         | Underspeed       | 45Hz    | > 5 s  |
| 7   |  | Phase loss selftest failure          | Overspeed        | 55Hz    | > 5s   |
| 8   |  |                                      | Over-temperature | T36/T37 | > 5 s  |
| 9   |  |                                      | Phase loss       |         | >0,1 s |
| 10  |  |                                      | Critical Error   | T36-T37 | > 5s   |
|   |   |                                      | 500V             |         | >0,1s  |
| <b>Note:</b> Critical error is either <b>Overvoltage</b> or <b>Overtemperature</b> (hardwired circuits) |   |                                      |                  |         |        |

## 2.2 Power-up and diagnose



For a successful self test, a remanent voltage of at least 11 V<sub>ac</sub> phase-phase and a frequency between 45 and 55Hz have to be present.  
Power-up self test takes approximately 15 seconds

| Error blink code |  <b>Green LED off</b> |   |  Ready <b>Green LED on</b> |   |
|------------------|--|---|---|---|
|                  | Reason   | Solution  | Reason  | Solution  |
| 1                | Operational contact failure  | Replace AVR.  | Voltage drop because of too high load   | Reduce load<br>Check for short circuit                          |
| 2                | Supply relay failure   | Replace AVR.  | Voltage drop because of too high load   | Reduce load   |
| 3                | Over voltage failure   | Replace AVR.  | RPM of prime mover unstable<br>AVR defect   | Reduce RPM<br>Replace AVR                                       |
| 4                | Error reset failure  | Replace AVR.  | RPM of prime mover unstable<br>AVR defect   | Reduce RPM<br>Replace AVR                                       |
| 5                | Temperature failure  | Replace AVR.  | RPM of prime mover unstable<br>AVR defect   | Reduce RPM<br>Replace AVR                                       |
| 6                | Measurement failure  | Check sensing wiring <sup>1</sup> .<br>Replace AVR. | RPM of prime mover too low<br>Coupling defect   | Increase RPM<br>Replace coupling                                |
| 7                | Phase loss failure   | Replace AVR.  | RPM of prime mover too high<br>Coupling defect  | Reduce RPM<br>Replace coupling                                  |
| 8                |  |   | Over temperature  | Check ventilation<br>Clean housing                              |
| 9                |  |   | Phase loss<br>Short circuit   | Check wiring<br>Check short circuit                             |
| 10               |  |   | Critical error  | Reduce RPM<br>Check ventilation<br>Clean housing<br>Replace AVR |

**Note 1:** For a successful selftest a minimum remanent voltage of 11V phase-phase has to be present.

**Table 3. Error codes and solutions**

## 2.3 ADJUSTING AND FACTORY SETTINGS

When delivered the AVR is ready to use with pre set factory settings. These settings are explained in table 4.

It is not advisable to change these settings because changing the factory settings can damage the generator and cause high voltage. Adjusting may only be done by qualified personnel who understand the danger of electric shock hazards and have read and understood the user instructions










|   |   |   |  |   |
|---|---|---|--|---|
|    | <b>Voltage setpoint:</b><br>Adjust the generator output voltage           | <b>Factory default</b><br>   | <b>Turning CW</b><br>Increase the output voltage           | <b>Turning CCW</b><br>Decrease the output voltage           |
|   | <b>P action setpoint:</b><br>Adjust the P-action control characteristic   | <b>Factory default</b><br>  | <b>Turning CW</b><br>Increase the Proportional gain action | <b>Turning CCW</b><br>Decrease the Proportional gain action |
|  | <b>I action setpoint:</b><br>Adjust the I-action control characteristic   | <b>Factory default</b><br> | <b>Turning CW</b><br>Increase the Integral action          | <b>Turning CCW</b><br>Decrease the Integral action          |
|  | <b>Droop setpoint:</b><br>Adjust the voltage droop for parallel operation | <b>Factory default</b><br> | <b>Turning CW</b><br>Increase the amount of voltage droop  | <b>Turning CCW</b><br>Decrease the amount of voltage droop  |

Table 4. Adjusting AVR setting (note CW=Clock wise CCW=Counter Clock wise)

## 2.4 Special functionality\*

The AVR has a unique feature of reducing the reference voltage. When a heavy load is switched on and the generator output voltage decreases below 370V, the AVR lowers the reference voltage to 370V. When the generator voltage is equal to the AVR reference voltage again, the AVR builds up to the normal voltage output threshold level again. This feature prevents the generator from producing a voltage overshoot due to heavy load switches in combination with an over-magnetized generator.



Voltage reference lowering due to heavy load change

\* Not implemented on 24V version

## 2.5 Electrical characteristics

| Parameter  | EME VD 110V <sub>dc</sub> AVR           | EME VD 24V <sub>dc</sub> AVR            |
|--|---|---|
| Sensing voltage input  | 3 x 400 V – 50 Hz                       | 3 x 400 V – 50 Hz                       |
| Supply input<br>UH, VH, UH', VH'                                 | 85V – 100V <sub>ac</sub> , 100 – 400 Hz | 85V – 100V <sub>ac</sub> , 100 – 400 Hz |
| Electronics supply<br>0-110V <sub>dc</sub> / 0-24V <sub>dc</sub> | 77 – 138 V <sub>dc</sub>                | 18 – 39 V <sub>dc</sub>                 |
| Field excitation current   | 3,7 A                                   | 3,7 A                                   |
| Field resistance   | 6 – 10 Ω                                | 6 – 10 Ω                                |
| Voltage setpoint range   | ± 5%                                    | ± 5%                                    |
| Operational contact  | 30V / 5A <sub>dc</sub>                  | 30V / 5A <sub>dc</sub>                  |
| Ambient temperature  | -20°C to +70°C, non condensing          | -20°C to +70°C, non condensing          |
| Storage temperature  | -30°C to +55°C, non condensing          | -30°C to +55°C, non condensing          |

Stresses above those listed under “Absolute Maximum Ratings” may cause permanent damage to the device. This is a stress rating only and functional operation of the device at those or any other conditions above those indicated in the operation listings of this specification is not implied. Exposure to maximum rating conditions for extended periods may affect device reliability and lifetime.

## 2.6 Wiring diagram






Fig 4. Wiring

## 2.7 Fault diagnoses


### 420V Overvoltage




### 380V Undervoltage




### 440V Overvoltage




### 340V Undervoltage:




### 500V overvoltage:




## Overspeed




## Underspeed



## Overtemperature







## 2.8 Factory settings

After service or repair the AVR is re-adjusted to factory settings which are:

| Parameter             | Value | Unit |
|-----------------------|-------|------|
| Output Voltage        | 400   | V    |
| Under speed frequency | 45    | Hz   |
| Over speed frequency  | 55    | Hz   |
| Droop                 | 0     | V    |

## 2.9 General installation information

### Absolute Maximum Ratings

- The Absolute Maximum Ratings are those limits for the device that, if exceeded, will likely damage the device. Exceeding the absolute maximum ratings voids any warranty and/or guarantee.

### Mounting

- Mounting of the product should be done in such a way that the absolute maximum ambient temperature rating of the product will never be exceeded.
- Mounting of the product should be done in such a way that maximum cooling (direction of cooling ribs and direction of airflow) is achieved.
- Mounting of the product should be done in such a way that no humid air can flow through the product or condensation occurs.
- Mounting of the product should be done in such a way that dust or other materials or residue will not remain in or on the product.
- Mounting of the product should be done in such a way that the maximum vibration is not exceeded.
- Mounting of the product should be done in such a way that personal contact with persons is impossible.

### Wiring

- Diameter size of the wiring should be enough to carry the expected current. Wire insulation should be enough to withstand the expected operating voltages and temperatures.
- To improve EMC emission and immunity, care should be taken for the lay out of the wiring. This in respect to all wiring in the installation.
- Keep current carrying wires as short as possible.
- Keep wires carrying a total sum of zero Ampere close to each other, or in one single cable. E.g. U, V, W or F+ and F-, or Phase and neutral, X1 and X2.
- Avoid current carrying conductors next to sensing or control wiring. Especially current controlled by SCR's or PWM controlled transistors.
- If sensitive sensing signal cables need to be laid across distance along other cabling, shielded cable is preferred.  
Keep the shield as long as possible and the wiring outside the shield as short as possible. Do not solder or shrink the shield to a regular wire. Connect the original shield to ground at one side with an as large as possible contact surface.

## Additional installation information

- When the product is supplied by means of a transformer, it should never be an auto-transformer. Auto-transformers react as voltage sweep up coil and may cause high voltage peaks.
- Standard fit capacitors or over-voltage suppressers across F+ and F- or exciter field terminals inside the generator should be removed.
- When the product is supplied by means of a transformer, it should be able to carry at least the maximum expected current. Advisable is, to have a transformer which can carry twice the maximum expected current. Inductive loads make voltage sags and peaks into the secondary voltage of a transformer, from which the device may malfunction.
- It is not recommended to apply switches in dc outputs. It is preferred to use switches in the ac supply inputs of devices. In case it is unavoidable to have switches in the dc output of a device, action must be taken to avoid over voltage damage to the device due to contact arcing. Use a voltage suppressor across the output.
- It is not recommended to apply switches or fuses in the sensing lines. Defects can cause high voltage situations due to over-excitation.
- When using a step down transformer in medium or high voltage generators, the transformer should be three phase (if three phase sensing), and the transformer should be suitable for acting as a sensing transformer. If the transformer is unloaded, connect a resistor to avoid voltage waveform distortion.
- The phase relation from the generator to the AVR is important. Also when voltage transformers and/ or current transformers are installed.
- When using a step down or insulation transformer in the droop circuit, phase relation from the generator to the AVR is important.
- CT's wiring, connected to the AVR should never be grounded.
- Always disconnect electronic products, circuits and people before checking the insulation resistance (Megger check).
- Due to differences in generators impedance's, EMC behavior is not predictable. Therefore the commissioner / installer should be aware of proper and correct installation.
- Large, highly inductive, exciter stator windings can cause destructive high voltage peaks. Adding a resistor from 10 to 20 times the exciter stator field resistance reduces voltage spikes. If necessary filter can be fitted additionally. (e.g. snubber, RC-network)
- Upon problems during commissioning, faulty behavior or defects in the generator, consult the fault finding manual at our web site
- Some advises may be overdone or seem extraordinary, but since the electrical rules are the same everywhere, these advises are given.